

00000-110000




FIG. 1

FIG. 2





FIG. 3






FIG. 4






FIG. 5

FIG. 6



000000-000000

FIG. 7



000000-11000000

000000-100000

FIG. 8






FIG. 9



000000" 11634500

FIG. 10



144 -140

192

FIG. 12

EVENT LOG

SYSTEM 1

▼

DOCUMENTATION

144

158

136

138

200

202

204

SYSTEM 1 SPREADSHEET VIEW

SELECT SORT

NONE

▼

○ ASCENDING

○ DESCENDING

○ NONE

206

SPARE PARTS

REPORTS

MANUALS

DRAWINGS

DEVICE SERIAL...	DATE	SECTION	LOCATION	DESCRIPTION	DEVICE TYPE	USER 1	USER 2	USER 3
1074397223	06 / 16 / 2000 14:12:54	3	A	SERIAL NO. CHANGE ON DEVICENET...	1336PLUSII			
1074397223	06 / 22 / 2000 11:03:26	3	A	SERIAL NO. CHANGE ON DEVICENET...	1336PLUSII			
1074397223	06 / 23 / 2000 15:32:47	3	A	NO COMMUNICATION	1336PLUSII			
1074397223	.	3	A	NO COMMUNICATION	1336PLUSII			
1074397223	.	3	A	NO COMMUNICATION	.			
1074397223	.	3	A	NO COMMUNICATION	.			
1074397223	.	3	A	FAULT	.			
.			
.			
.			

SHOW / HIDE COLUMNS...

FIG. 13

144, 140

210.
208.
138 -
136 ↗

